



# CSS – OD / 90 kWh Grid-tied Commercial Energy Storage Solution

Model CSS-OU-090 / PCS050B


## Quick Installation Guide


Version 1.0


Preliminary

Draft 19-11-2025


## Legend


 **WARNING!** This symbol denotes a hazard. It calls attention to a procedure that if not correctly performed or adhered to could result in injury or loss of life. Do not proceed beyond a warning note until the indicated conditions are fully understood and met.

 **CAUTION!** Denotes a hazard. It calls attention to a procedure that, if not correctly performed or adhered to, could result in damage or destruction of the product. Do not proceed beyond a caution sign until the indicated conditions are fully understood and met.


 This symbol indicates that this is the Protective Earth (PE) terminal that must be firmly grounded to ensure the safety of operators.

## Safety Instructions


 **WARNING: RISK OF ELECTRIC SHOCK**  
DO NOT touch the wires, contacts, terminals, or any conductors connected to the grid circuit inside the equipment.  
Failure to follow safety instructions could result in severe injury or death from electric shock.


 **WARNING: LETHAL HIGH VOLTAGES exist inside the product.**


- Note and abide by all warning signs on the product.
- Observe the safety precautions listed in this manual and other related documents.

 **WARNING: Damaged Equipment Hazards**

- Damaged equipment or system failure may cause electric shock or fire!
- Perform an initial visual inspection of the equipment for damage or other hazards before operation.
- Check whether other external devices or circuit connections are secure.
- Confirm that this equipment is in a safe state before operating it.

 **WARNING:** This equipment must be installed by **licensed electrician** and qualified personnel only. The installation and wiring of this equipment must comply with all applicable national, state/provincial, local electrical codes and standards. Attempting installation by unqualified individuals could result in unsafe operation, code violations, personal injury/loss of life, or damage to the equipment.

 **WARNING: Battery Protection**  
DC HIGH VOLTAGE! ELECTRIC SHOCK HAZARD!  
The battery in the system generates a high voltage when connected. Accidental contact can result in electric shock or life-threatening injuries.

 **WARNING: Ground Fault Safety Warning**  
If a ground fault occurs in the Battery Inverter, high voltage may appear on components that are normally not energized. **Accidental contact with these components can cause serious injury or death.**  
Before Operating the system

- Check for ground faults: Ensure the system is free of any ground faults.
- Apply protective measures: Implement all required safety precautions before starting operation.

A ground fault can make normally safe parts dangerously live. Always verify system integrity and follow safety protocols to protect yourself and others.

### **WARNING: Live Line Measurement**


- There are high voltages in the equipment in the integrated Battery Inverter, and accidental touch may cause fatal electric shock hazards.
- During live measurement, take appropriate protection, such as wearing insulating gloves.
- There must be an accompanying person to ensure personal safety.

### **WARNING: Improper parameter settings**

- Improper parameter settings may affect the normal function realization of internal devices.
- Only authorized professionals can set the parameters.

### **WARNING: Regulatory Compliance**

The installation and various operations of the integrated PCS must comply with the relevant standards and regulations of the country/region where the project is located.

 **WARNING:** The inverter should not be directly connected to life support equipment or medical equipment.



## Personal Protective Equipment



Safety Rubber Shoes



Helmet



Rubber Gloves



Safety Clothing



Goggles

## Required tools for Battery Cabinet 90 kWh & Battery Inverter



WARNING! Use only insulated tools



Torque wrench with 7mm, 10mm, 16mm, 17mm, 18mm, 19mm sockets



Wire Cutter



Crimping tool



Phillips screwdriver M4, M6, M10 L= 230 mm



Heat gun



Multimeter ( $\geq 1000 V_{DC}$ )



Cable Stripper



Wire Stripper



Drill ( $\varnothing 10$  mm drill)



Box Cutter



Pipe Cutter



Ladder



Rubber Hammer



Slotted Screwdriver (10 mm slot)



Slotted Screwdriver for Terminal Block Screws (2 mm slot)



Adjustable Wrench



Open-end torque wrench



1. Explosion Relief Panel
2. Four Eye Bolts
3. Acoustic-Visual Alarm
4. Emergency Power Off (EPO) switch
5. CSS Local Interface Display (EMS)
6. Battery Inverter 1
7. Door Lock

8. Nameplate
9. Wiring Duct
10. Intake Valve (on back side of cabinet)
11. Aerosol Fire Extinguisher 1
12. Energy Modules Management Unit
13. Energy Module (x5)
14. Aerosol Fire Extinguisher 2

15. CO Detector
16. Smoke Detector
17. Fire Fighting Valve
18. Wiring Duct (optional)
19. Battery Inverter 2 (optional)
20. Exhaust Valve

Battery Cabinet 90 kWh



Battery Inverter 50 kW



Battery Inverter 50 kW  
Battery Cabinet 90 kWh


\*Assembled Dimensions



All dimensions are in [mm]

## Default Layout &amp; Clearance Distances (Top &amp; front view)

All dimensions w/o units are in [mm]



Battery Cabinet + Battery Inverter	
Direction	Distance [mm]
Front	1200
Rear	400
Right	1400
Left	1000 (600 from Battery Inverter)



**WARNING!** To avoid flood damage and safety hazards, the cabinet must be installed on a concrete platform with a minimum height of 300 mm.



**Above ground: Minimum 300**

**Below ground: Minimum 400**

**NOTES!**

- Local codes and regulations could extend the required clearances beyond what is specified in this manual
- Before proceeding with installation, consult with relevant authorities to ensure compliance with local regulations concerning clearance distances.

## CAUTION

1. The installation, use, and operation of outdoor equipment and cables, including but not limited to the movement of equipment, operation of devices and cables, connection or disconnection of signal interfaces exposed to outdoor conditions, and work at heights. Outdoor installations are strictly prohibited during severe weather conditions such as lightning, rain, snow, or high winds.
2. Avoid installing the equipment near underground facilities like underwater pipes and air outlets or in places prone to condensation. Additionally, steer clear of areas susceptible to water leakage, such as around air-conditioning outlets, vents, and outlet windows in the machine room. This will help prevent liquids from entering the equipment and causing malfunctions or short circuits.
3. Avoid installing the equipment in areas with poor geological conditions, such as rubbery or weak soil, waterlogged ground, or regions susceptible to land subsidence. When installing in a sandy environment, increase the frequency of routine maintenance for the battery vent and HVAC systems: perform a visual inspection weekly and clean as needed based on observed conditions.
4. Do not place the equipment or operate it in a flammable environment or an environment that contains explosive gas or smoke.
5. Avoid installing the battery cabinet in sandy environments.
6. Avoid installing the battery cabinet on unstable or vibrating foundations.
7. Do not install the battery cabinet in a working environment with metal conductive dust.
8. When the equipment is running, do not cover the vents or heat dissipation system to prevent fire due to high temperature.



**CAUTION!** For indoor installations ventilated room is required.



**CAUTION!** CSS – OD solution must be installed: >2km from the sea, when installed in an outdoor location, or >1km when installed in indoor locations.



**NOTE** Battery Cabinet & Battery Inverter max noise is <65 dBA @ 1 meter distance.



**CAUTION!** When Installed in indoor locations consider heat dissipation values of all installed devices when choosing appropriate room / space for their installation.


Battery Cabinet	
Max Power	Heat Dissipation
50 kW	0.87 kWh 2970 BTU
Battery Inverter	
Max Power	Heat Dissipation
50 kW	1.5 kWh 5118 BTU



## **IMPORTANT NOTE!**

1. Communication cables and power wires **must** be laid separately (DC and AC loops).
2. The distance between control/communication and power cables must be greater than 300mm.
3. In cases when control cables cross power cables, validate that the angle between the two cables is kept at 90°.
4. The recommended minimum distance between parallel shielded data cables and power cables is shown below:

Parallel length (m)	Min space distance (m)
200	0.3
300	0.5
500	1.2




- Three Phase AC Cable, multi stranded class 5 or 6, 25-35 mm<sup>2</sup>, 50 kW
- Single Phase Auxiliary AC Cable (not provided)
- Modbus TCP Communication Cable (LAN)
- RS485 Comm. Cable (not provided)



# Handling and Inspecting Before Unpacking



## NOTES:

- Keep in upright position 
- Before opening, validate package integrity



**IMPORTANT:** Do not open damaged packages & contact SolarEdge to review the case.

**NOTE:** For SolarEdge commercial Battery storage and transportation guidelines refer to:  
<https://knowledge-center.solaredge.com/sites/kc/files/se-commercial-battery-storage-transportation-and-storage-guideline-90kwh-eng.pdf>




## NOTES: For Battery Cabinet Package


- Verify that the shock and tilt label sensors, on the front and right sides of the package, show green indication.
- When opening package, check the integrity of the fire safety solution. If aerosol gas was ejected due to any fault occurred during transportation the battery cabinet shall be replaced.
- If one of the sensors is red, please contact SolarEdge and do not open the package.



## Transporting Battery Cabinet with the Wooden Box




## Transporting Battery Cabinet Standalone



## Forklift Requirements

**WARNING!** Forklift must be able to lift At least 5 tons carrying capacity



## HOISTING REQUIREMENTS


### WARNING!


1. A trained and qualified lifting personnel is required.
2. Do not operate a hoist if severe weather or wind is apparent when conducting hoisting outdoors.
3. Keep unauthorized people from entering the area and standing under crane boom.
4. Ensure that the crane and slings meet the load-bearing requirements.
5. To prevent the cabinet from scratching, do not drag it when installing and removing hoisting equipment.
6. Check to ensure that the hoisting tools are in good condition.
7. Ensure that all the doors of the equipment are closed and locked during transportation.


### Standalone Battery Cabinet Crane Transportation



### Packaged Battery Cabinet Crane Transportation



 **WARNING!** Do not tilt the cabinets during transportation.




# Mounting Battery Cabinet on Concrete Base Platform


## Option 1: Unified Concrete Platform Base with Embedded Steel Plate with Studs

**NOTE:** Bolts, nuts, and washers are not supplied. Torque depends on the mounting pad. For concrete pads use 60 Nm.


**NOTE:** Concrete pad guidelines are in Appendix B




## Option 3: Unified Concrete Platform Base with Drilling Occurs on Site



## Option 2: Hollow Concrete Platform Base with Embedded Steel Plate with Studs




## Option 4: Hollow Concrete Platform Base with Drilling Occurs on Site




## Battery Cabinet Package Contents (Inside Accessories Box)




**PAY ATTENTION!**  
All Cables are marked  
with a designation label



Forklift Slots Covers (x4) (Y)  
(Outside Accessories Box)



Battery Cabinet  
Wiring Duct (G)




PE cable (0.7m) (E)



## Battery Cabinet Package Contents (Inside Battery Cabinet)

Sealant (x2) (H)



Corrugated Plastic  
Conduit  $\varnothing 34.5$  mm (I)



Corrugated Plastic  
Conduit  $\varnothing 21$  mm (J)





## Battery Inverter Package Contents


Battery Inverter  
Mounting Bracket kit (K)



Battery Inverter




Bracket M10  
Mounting Bolts  
(x12) (Q)




Bracket Lock  
M6 Bolts  
(x2) (R)



Right-angled Torx  
Star Allen key (P)



Cables Shrinks  
(x15) (T)



M6 Lugs (x15) (S)




NOTE: These lugs are compatible with class 2 wires. Please ensure you provide your own lugs if class 5 or 6 wires are used on site.




Cabling Package Contents

Battery Cabinet to Battery Inverter DC Cables (3.5m) (B)



Battery Cabinet to Battery Inverter DC Cables (3m) (A)




AC Auxiliary Cable (x1) (5m) (W)




Modbus TCP Cable (Ethernet) (x1) (5m) (X)




Battery Cabinet to Battery Inverter COM cable (3.5m) (C)




PAY ATTENTION!  
All Cables are marked with a designation label




# Mounting Battery Inverter onto the Battery Cabinet







# Battery Inverter to Battery Cabinet DC Wiring




# AC Wiring of Battery Inverter to Grid

## Battery Inverter




**WARNING!** To ensure proper and safe grounding, a Ground wire must be connected between the Backup Load and Grid PE terminals.



**NOTE:** Strip  $\leq 240\text{mm}$  of the cable jacket

**NOTE:** Cable properties: (Not supplied)

- Multi-stranded class 5 or 6 flexible **copper** conductors
- $35\text{mm}^2$  cross-section wires cable.
- Grid Cable maximum current is 160 A (per phase)
- Crimp M6 lugs provided. Lugs fit class 2 cables. For class 5 or 6, bring your lugs.
- To keep the gland sealed, use 5C or 4C cable type. (3ph+N+PE or 3ph+PE)



Neutral (N) wire is optional,  $16\text{mm}^2$ , M6 lug (Not supplied)




**WARNING!** Connect the ground wires in accordance with local regulations.


**NOTES:**

1. Recommended Grid circuit breaker parameters: 4P 200A/690VAC. If RCD is requested, use type A, 300 mA
2. Recommended Backup Load and Generator circuit breaker parameters:  $\geq 125\text{A}/\geq 400\text{Vac}$

## AC Distribution Box


(Infrastructural preparation of the client, not supplied by SolarEdge)






# Wiring Communication between Battery Cabinet & Battery Inverter

## COM Connector Wiring




## Battery Inverter




Get parts from:  
Battery Cabinet Package **C** and **D**


## Battery Cabinet



## Battery Cabinet




CAN Communication  
RS-485 Communication




Com Cable









## Connecting External Meter







# Sealing and Closing Wiring Duct Lid and Panels


**IMPORTANT!** Use fire clay sealant to block the cable exit gaps and seal unused wiring holes.



Fire Clay Sealant (x2) (H)



Get parts from: Battery Cabinet Package (H, G [Duct Cover])



From Battery Inverter

7mm X 10  
1.8~2.4 Nm

External Cabling in/out


A dark blue diagonal stripe runs from the bottom-left corner towards the top-right corner, dividing the page into two sections.

# Appendix A

## Powering the CSS-OD

# Power On Sequence

Follow the numbered steps to power-on the system




**CAUTION!** Before powering up the Battery Inverter, it is necessary to verify the connection of all cables and make sure they are correct and tight.

8


EMS Screen

1. Click : Settings → Battery Inverter → Battery Inverter ON/OFF → ON.
2. Enter password: 000000, issue Inverter power on command. The → Battery Inverter ON/OFF button changes from green to gray, and the Running LED light changes from steady red to green.
3. Click Home to check device status, active power, and DC voltage to confirm successful operation.
4. Click the Device tab to check the operating status and voltage of Inverter and battery cabinet to confirm successful operation.




# Power Off Sequence

Follow the numbered steps to power-off the system




1. Click: **Settings** → **Battery Inverter** → **Battery Inverter ON/OFF** → **OFF**.
2. Enter password: 000000, issue Inverter shutdown command. The shutdown button changes from green to gray, and the Running LED changes from steady green to flashing red.



A dark blue diagonal stripe runs from the bottom-left corner towards the top-right corner, separating the dark blue header area from the white content area.

## Appendix B

### Commissioning



1. Tap **Settings** for:

- Turning the inverter power ON/OFF
- Setting max power generation limit
- Changing Grid code
- Network Settings
- Firmware version, update and reset

2. Tap **Alerts** for Error and fault messages

3. Tap **Devices** to view cabinet temperature



A dark blue diagonal graphic element that starts from the bottom-left corner and extends towards the top-right, creating a triangular shape on the left side of the page.

# Appendix C

## Troubleshooting and Maintenance

**NOTE:** For CSS-OD routine maintenance guide, refer to: <https://knowledge-center.solaredge.com/sites/kc/files/se-css-od-90-routine-maintenance-guide.pdf>

Fault Description	Possible Cause	Corrective Action
Grid Overvoltage	Grid voltage above permissible limit	<ul style="list-style-type: none"><li>• Check Grid Code settings</li><li>• Check grid voltage with a multimeter.</li><li>• Contact utility provider if voltage remains high.</li></ul>
Grid Undervoltage	Grid voltage below permissible limit	<ul style="list-style-type: none"><li>• Verify connection at AC terminals.</li><li>• Check for utility fluctuations or loose wiring.</li></ul>
Grid Frequency Error	Frequency outside 50/60 Hz $\pm 0.5$ Hz	<ul style="list-style-type: none"><li>• Confirm local grid frequency stability.</li><li>• Wait for automatic reconnection once frequency normalizes.</li></ul>
Insulation Resistance Fault	Low insulation resistance detected on DC side	<ul style="list-style-type: none"><li>• Check for good earth resistance of BT+ and BT– battery terminals is greater than 2 M<math>\Omega</math>.</li><li>• Replace defective module or cable.</li></ul>
Ground Fault	Leakage current detected	<ul style="list-style-type: none"><li>• Inspect for damaged cables or moisture ingress.</li><li>• Dry the system and re-test insulation.</li></ul>
Temperature Overheat	Inverter temperature exceeds safe limit	<ul style="list-style-type: none"><li>• Ensure ambient temperature is within range.</li><li>• Clean heat sink and check for blocked airflow.</li><li>• Verify fan operation (if equipped).</li></ul>
Communication Failure	Lost connection with SolarEdge ONE system	<ul style="list-style-type: none"><li>• Check communication wiring and connectors.</li><li>• Verify that SolarEdge ONE Controller is powered.</li><li>• Verify that your site router is powered and connected to the internet.</li></ul>

A dark blue diagonal stripe runs from the bottom-left corner towards the top-right corner, separating the dark blue header area from the white content area.


# Appendix D

## Construction Details

## IMPORTANT NOTES!


1. Battery Cabinet must be installed on a reinforced concrete platform base.
2. Dig a trench or reserve a cable entry hole by considering the electrical wiring of the equipment before construction of the foundation.
3. The foundation must be made of non-combustible materials.
4. The bearing capacity of the foundation shall be  $> 3$  t.
5. When designing and manufacturing the embedded steel plates for the battery cabinet, it is necessary to consider that there must be a reliable connection (reinforcement hook) between the embedded steel plate and the concrete base.
6. When molding the concrete pad, it shall protrude below the ground a minimum of 400 mm.
7. To avoid flood damage and safety hazards, the cabinet must be installed on a concrete platform with a minimum height of 300 mm. The Concrete base surface smoothness shall be  $\leq 3$ mm.
8. The upper surface tolerance of the foundation shall be  $\pm 5$ mm.
9. The concrete pad shall prevent rainwater accumulation on top of it. The foundation construction should meet the drainage requirements for the maximum volume of rainfall in the locality, and the discharged water needs to be treated in accordance with local laws and regulations.
10. The foundation drawing is only for reference and cannot be regarded as the final construction drawing. Operators shall recheck the basic parameters according to the environment, geological conditions, seismic requirements, etc., of the installation site.

## Concrete Platform Base





## Embedded Steel Plate with Studs

### Embedded Steel Plate 100 / 10



All dimensions are in mm





#### **Support Contact Information**

If you have technical problems concerning SolarEdge products, please contact us:

<https://www.solaredge.com/service/support>

Subject to change without notice.

Copyright © SolarEdge Inc.

All rights reserved. November 2025.