



Wi-Fi / ZigBee Antenna Installation

Kit Contents

- Antenna with the attached clip and cable
- Mounting bracket and 2 screws (for StorEdge Three Phase Inverters only*)



For additional languages, click [here](#), or scan the QR code.

Before you Begin


If the inverter has not been installed, install the inverter before installing the antenna.

If the inverter has been installed:


- Turn off the inverter ON/OFF/P switch. Wait 5 minutes for the capacitors to discharge.
- Turn off the Inverter Safety Switch (if applicable).
- Shut down AC to the inverter on the distribution panel.

Installing the Antenna


1. Install the antenna in one of the following ways. For maximum range, make sure to position the antenna upright.
 - Clip the antenna to the inverter side or heatsink fins and pass the cable between the inverter and mounting bracket.



- Clip the antenna to a bracket (not supplied by SolarEdge) attached to a vertical surface. SolarEdge recommends using a bracket with the following dimensions:



- **For StorEdge Three Phase Inverters only** – Install the supplied mounting bracket and clip the antenna to the bracket. Pass the cable between the inverter and mounting bracket.



* StorEdge Three Phase Inverters are available in some regions only.